

# None, Nada, Zero, Zip...

**..absolutely no clearance needed for the Summit Lock,  
and no need to purchase a locking liner.**

**The Summit Lock converts a cushion liner into a locking liner.**

**The Summit Lock is designed for long limb types that  
do not have the clearance for distal suspension.**

Attachment is glued to fabric backed liner.  
(see website for preferred liner options)



By attaching to the liner on the inside  
of the socket and locking on the  
outside of the socket, it is the first lock  
developed that controls rotation.

The tab feeds out of a hole in the socket and  
walks itself into the lock after initial engagement.  
(this can be done from a seated position)

**Coming Soon!  
New LowPro Summit  
designed for easier  
engagement and improve  
cosmetic finishing.**

Lock is riveted to the outside of socket.

**Coyote Design & Mfg.  
(800) 819-5980 or (208) 429-0026  
[www.coyotedesign.com](http://www.coyotedesign.com)**

